



Floor Truss Span Chart

Each individual floor truss design is unique based on multiple variables: geometry, loading, spacing, bearing conditions, etc. Span Tables below illustrate common combinations of the multiple variables available.

		TCLL = 40 psf				TCLL = 80 psf				TCLL = 125 psf			
		Truss Spacing				Truss Spacing				Truss Spacing			
		12"	16"	19.2"	24"	12"	16"	19.2"	24"	12"	16"	19.2"	24"
Truss Depth	12"	26	25	22	20	21	18	18	16	17	16	14	13
	14"	29	27	25	23	24	21	20	18	20	18	17	15
	16"	33	32	28	26	28	24	22	20	22	20	19	17
	18"	36	35	31	29	29	26	24	22	25	22	21	19
	20"	40	37	34	31	32	29	27	25	27	24	22	21
	22"	44	39	37	34	34	31	29	26	29	26	24	22
	24"	47	42	39	36	37	33	31	28	31	28	26	24

General Notes:

1. TCLL – Top chord Floor Live Load
2. TCDL = 10 psf and BCDL = 5 psf
3. Spans shown are in feet
4. Deflection Limits: Live Load – L/480, Total Load – L/360
5. Top and Bottom Chords braced by structural sheathing
6. Openings are to be located in the center of the span, max opening width is 24 inches
7. Single spans only